

MAINTENANCE

- If don't use for a long time, please clean the machine after final use.
- Every one- two months clean one time.
- Before change to another flavor of the essential oil,
- Cleaning steps as below:
 - 1, Put the 95% alcohol into the empty bottle,
 - 2, Set the strongest intensity, turn on the machine to work for 10-15 minutes,
 - 3, Turn off it and finally pour away the alcohol.

WARRANTY POLICY

- Warranty Period: 1 year, starting from the date we sold.
- Warranty is offered for all qualified machines. During warranty, we will offer repair services and the free parts.
- The warranty card & purchase Invoice are needed if after service required. Please do contact with us within warranty if any problems
- Listed below is not belong to our warranty service area.
 - *The consumers do not follow the product user manual to use and maintenance, and cause damage.
 - *Without our consent, consumers open or repair the device by themselves, and cause damage.
 - * Damaged & problems caused by Accidents & Fire.
 - *Not use properly and wrong operation.
 - *If repaired by not professional person and make some parts damaged.
 - *Be damaged during the transportation.
 - *Without warranty card.
 - *Without proper cleaning for a long time
 - *Machines & Parts are not from us.
 - *Machines are not gotten from official channels.
 - *Send the machines back without permit from manufacturer

TROUBLE SHOOTING

Condition	Solution
Not working	Add the battery or connect the power adapter
No Diffusing	Not at the working time; or contact us to check the pump.
No Mist	Clean the machine with alcohol. Not at the working time; Oil is used out.
Noisy	Contact us to check the pump
Oil Leaking	Keep the machine upright; Change the seal tape; Make sure the bottle is screwed in straight and snug.
No LCD	Sure the power is connected

If our above solutions are not workable, or any other condition we did not mention above, please send us the video of the problem you met, thank you!

SECURITY WARNING

- Please avoid machine working without oil in the long time.
- Please be sure the machine without any essential oil inside the bottle during transportation.
- Please make sure the machine upright, no leaking and no down; or may damage the device and parts.
- Please tighten the oils bottle and the bottle seal.
- Please do not use the rotten power wire and make sure the power supply is suitable for the machine, or may cause fire.
- Please don't open the machine by yourself
- DO NOT block the vents to ensure the internal parts stay in cool.
- Keep the diffuser away from children, water, fire and other danger items.
- Please clean the machine with alcohol every 1-2 months.

2000 CBM SCENT DIFFUSER

Be charming be happy

By the Scent Marketing



User Manual

QC CARD

QC Name	
Date	

WARRANTY CARD

Date	Content	Person

PRODUCT INTRODUCTION

Introduction

This scent Equipment is 3 in 1, could connect to the HVAC system, wall mounted or stand-alone.

It covers from 1000 to 2000 cubic meters commercial places included shopping malls, supermarkets, office buildings, Cinemas and more.

With 1000ml big aluminum oil bottle, it could last for a long time so that no need to refill the oil all the time.

Accessories Checking

Empty Oil Bottle	1	User Manual	1
Screws Connector	4	Screws	4
Spare Atomizing Core	1	Power Adapter	1
Wall Mounted Panel	1	Air Tube	1
Keys	2	Connector	1

Technical Data


Coverage	1000-2000m3	Power	DC12V14W
Color	Black, White	Material	Iron
Size	390*240*150mm	N. Weight	5.5kg
Bottle	1000ml	Noise	<42DBA
Installation	Connect HVAC/wall mounted/standalone		

PROGRAM SETTING

Setting Steps

1. Add the essential oil into the empty oil bottle
2. Insert the air tube into the air tube connector (for HVAC installation)

3. Connect the power supply
4. Set the local time, working time and the essential oil intensity.



Step 1, Add the Essential Oil into the Empty Oil Bottle

Take out bottle → Open the bottle → Add the oil → Close the bottle → Put back the bottle into diffuser



(Attention: For the first time use, it must be put oil inside without electricity before timer setting; also please tighten the oil bottle)

If need to change the oil, please cut down the power supply. Then open the machine rotate the empty oil anticlockwise to take out the bottle to put the oil in again and finally clockwise rotate the bottle and make sure it is tight. Then connect the power supply again.

Step 2, Power Supply

- Make the adapter connect the machine, and then make the adapter plug insert into 110-240V power socket.



Step 3, Local Time Setting

- Turn ON the machine, the LCD display will indicate the Beijing Time
- For the first time use, we need to change the Chinese Time to your local country time.
- Setting Steps as below
- Firstly to press **【SET】** to change the hour, press **【UP/DOWN】** to adjust hour.
- Press **【SET】** to change the minute, then press **【UP/DOWN】** to adjust the minutes
- Press **【SET】** to change the day, then press **【UP/DOWN】** to adjust the day
- Press **【SET】**, then all function setting finished.

Step 4, Working Time and Intensity Setting

- The machine can be set 4 different working groups, different

working days and the different intensity.

- Setting Steps as below
1. First time to press **【MODE】**. Then press **【SET】** to set the START TIME of the 1st group. Press **【UP/DOWN】** to adjust the hours; Press **【SET】** and press **【UP/DOWN】** to adjust the minute; Press **【SET】** and press **【UP/DOWN】** to adjust the working day;
 2. Second time to press **【MODE】**. Then press **【SET】** to set the STOP TIME OF 1st group. Press **【UP/DOWN】** to adjust hours; Press **【SET】** and press **【UP/DOWN】** to adjust the minute
 3. Third time to press **【MODE】** to set the AROMA CONCENTRATION of 1st group. Press **【UP/DOWN】** to adjust the aroma concentration. Every time you can adjust 1 (such as 1, 2, 3,...), the maximum is 9, the minimum is 1.
 4. The 1st group is set well; If continue to set the other working groups, continue to press **【MODE】** to finish the other 3 working groups at the same method.

- Notice: If run time across the 00:00. It needs to set two separate run groups. The 1st group STOP TIME is 23:59; the 2nd group START TIME should be 0:01.
- Press **【DOWN】** last 10 seconds to Restore factory settings.
- In each group, the STOP TIME could not be earlier than the START TIME.
- Press **【MODE】** last 3 seconds to unlock the program.

INSTALLATION OF CONNECT TO HVAC SYSTEM

- 1: Confirm the position of the machine as shown as below photo.
- 2: Connect the air tube into the HVAC system. The hole of the tube must be higher than the scent machine, and the direction of tube should be downwind.
- 3: After confirming the position of the tube, punch the hole and fix the air tube in the hole with a tie wrap.

