



## PRODUCT INTRODUCTION

### ● Introduction

This scent Equipment is 3 in 1, could connect to the HVAC system, wall mounted or stand-alone.

It covers from 3000 to 5000 cubic meters commercial places included shopping malls, supermarkets, office buildings, Cinemas and more.

With 1000ml big aluminum oil bottle, it could last for a long time so that no need to refill the oil all the time.

### ● Accessories Checking

Empty Oil Bottle	1	User Manual	1
Screws Connector	4	Screws	4
Spare Atomizing Core	1	AC Power Adapter	1
Wall Mounted Panel	1	Air Tube	1
Keys	2	Connector	1

### ● Technical Data

Coverage	3000-5000m3	Bottle	1L
Color	Black, White	Material	Iron
Size	390*270*185mm	N. Weight	7.5kg
Power	110-220V/ 26W	Noise	<50DBA
Installation	Connect HVAC/wall mounted/standalone		

## PROGRAM SETTING


### ● SETTING STEPS

1 Add the essential oil into the empty oil bottle

2 Insert the air tube into the air tube connector

3 Connect the power supply

4 Set the local time, working time and the essential oil intensity.



## Step 1, Add the Essential Oil into the Empty Oil Bottle

Take out bottle ➡ Open the bottle ➡ Add the oil ➡  
Close the bottle ➡ Put back the bottle into diffuser



(Attention: For the first time use, it must be put oil inside without electricity before timer setting; also please tighten the oil bottle)

If need to change the oil, please cut down the power supply .Then open the machine rotate the empty oil anticlockwise to take out the bottle to put the oil in again and finally clockwise rotate the bottle and make sure it is tight. Then connect the power supply again.

## Step 2, Power Supply

- Make sure the adapter connect the machine, and then make the adapter plug insert into 110-240V power socket.



## Step 3, Local Time Setting

- Turn ON the machine, the LCD display will indicate the Beijing Time
- For the first time use, we need to change the Chinese Time to your local country time.
- Setting Steps as below
- Firstly to press **【SET】** to change the hour , press **【UP/DOWN】** to adjust hour.
- Press**【SET】** to change the minute, then press **【UP/DOWN】** to adjust the minutes
- Press **【SET】** to change the day, then press **【UP/DOWN】** to adjust the day
- Press **【SET】** , then all function setting finished.

## Step 4, Working Time and Intensity Setting

- The machine can be set 4 different working groups, different

working days and the different intensity.

- Setting Steps as below
- 1. First time to press **【MODE】**. Then press **【SET】** to set the START TIME of the 1<sup>st</sup> group. Press **【UP/DOWN】** to adjust the hours; Press **【SET】** and press **【UP/DOWN】** to adjust the minute; Press **【SET】** and press **【UP/DOWN】** to adjust the working day;
- 2. Second time to press **【MODE】** . Then press **【SET】** to set the STOP TIME OF 1<sup>st</sup> group. Press **【UP/DOWN】** to adjust hours; Press **【SET】** and press **【UP/DOWN】** to adjust the minute
- 3. Third time to press **【MODE】** to set the AROMA CONCENTRATION of 1st group . Press **【UP/DOWN】** to adjust the aroma concentration. Every time you can adjust 1 (such as 1, 2, 3...), the maximum is 9, the minimum is 1.
- 4. The 1st group is set well; If continue to set the other working groups, continue to press **【MODE】** to finish the other 3 working groups at the same method.
- Notice: If run time across the 00:00. It needs to set two separate run groups. The 1st group STOP TIME is 23:59; the 2nd group START TIME should be 0:01.
- Press **【DOWN】** last 10 seconds to Restore factory settings.
- In each group, the STOP TIME could not be earlier than the START TIME.
- Press **【MODE】** last 3 seconds to unlock the program.

## INSTALLATION OF CONNECT TO HVAC SYSTEM

- 1: Confirm the position of the machine as shown as below photo.
- 2: Connect the air tube into the HVAC system. The hole of the tube must be higher than the scent machine, and the direction of tube should be downwind.
- 3: After confirming the position of the tube, punch the hole and fix the air tube in the hole with a tie wrap.

