

MAINTENANCE

- If don't use for a long time, please clean the machine after final use.
- Every one- two months clean one time.
- Before change to another flavor of the essential oil,
- Cleaning steps as below:
 - 1, Put the 95% alcohol into the empty bottle,
 - 2, Set the strongest intensity, turn on the machine to work for 10-15 minutes,
 - 3, Turn off it and finally pour away the alcohol.

WARRANTY POLICY

- Warranty Period: 1 year, starting from the date we sold.
- Warranty is offered for all qualified machines. During warranty, we will offer repair services and the free parts.
- The warranty card & purchase Invoice are needed if after service required. Please do contact with us within warranty if any problems
- Listed below is not belong to our warranty service area.
 - * The consumers do not follow the product user manual to use and maintenance, and cause damage.
 - * Without our consent, consumers open or repair the device by themselves, and cause damage.
 - * Damage & problems are caused by Accidents & Fire.
 - * Not use properly and wrong operation.
 - * If repaired by not professional person and make some parts damaged.
 - * Be damaged during the transportation.
 - * Without warranty card.
 - * Without proper cleaning for a long time
 - * Machines & Parts are not from us.
 - * Machines are not gotten from official channels.
 - * Send the machines back without permit from manufacturer

TROUBLE SHOOTING

Condition	Solution
Not working	Add the battery or connect the power adapter
No Diffusing	Not at the working time; or contact us to check the pump.
No Mist	Clean the machine with alcohol. Not at the working time; Oil is used out.
Noisy	Contact us to check the pump
Oil Leaking	Keep the machine upright; Change the seal tape; Make sure the bottle is screwed in straight and snug.
No LCD	Sure the power is connected

If our above solution is not workable, or any other condition we did not mention above, please contact us , thank you!

SECURITY WARNING

- Please read carefully before use and keep properly.
- Please avoid machine working without oil in the long time.
- Please be sure the machine without any essential oil inside the bottle during transportation.
- Please make sure the machine upright, no leaking and no down; or may damage the device and parts.
- Please tighten the oils bottle and the bottle seal.
- Please do not use the rotten power wire and make sure the power supply is suitable for the machine, or may cause fire.
- Please don't open the machine by yourself
- DO NOT block the vents to ensure the internal parts stay in cool.
- Keep the diffuser away from children, water, fire and other danger items.
- Please clean the machine with 95% alcohol every 2 months.

CYLINDER SCENT DIFFUSER

Be charming be happy

By the Scent Marketing



User Manual

QC CARD

QC Name	
Date	

WARRANTY CARD

Repair Date	Content	Repair Person

PRODUCT INTRODUCTION

Introduction

This cylinder scent Equipment is designed with classic style for small commercial places or homes. It uses advanced atomization technology to make the liquid oil into mist, and then can diffuse the fragrance into the air quickly.

The machine can be used directly to diffuse the fragrance quickly. It has a timer program to adjust different aroma concentration to suit for different space and set the working time for 7 days/24 hours.

Accessories Checking

Empty Oil Bottle	1	User Manual	1
Spare Atomizing Core	1	AC Power Adapter	1

Technical Data

Coverage	100-200m3	Power	5W12V
Color	Black, Silver	Material	Aluminum
Size	112*70*285mm	N. Weight	1.3kg
Installation	Tabletop	Noise	<38DBA

PROGRAM SETTING

SETTING STEPS

- 1 Add the essential oil into the empty oil bottle
- 2 Connect the power supply
- 3 Set the local time same as your country
- 4 Set the working time and the intensity

Step 1, Add the Essential Oil into the Empty Oil Bottle

Take out bottle ➡ Open the bottle ➡ Add the oil ➡
Close the bottle ➡ Put back the bottle into diffuser



(Attention: For the first time use, it must be put oil inside without electricity before timer setting; also please tighten the oil bottle)

If need to change the oil, please cut down the power supply .Then open the machine rotate the empty oil anticlockwise to take out the bottle to put the oil in again and finally clockwise rotate the bottle and make sure it is tight. Then connect the power supply again.

Step 2, Power Supply

- Make sure the adapter connect the machine, and then make the adapter plug insert into 110-240V power socket.




Step 3, Local Time Setting

- Turn ON the machine, the LCD display will indicate the Beijing Time
- For the first time use, we need to change the Chinese Time to your local country time.
- Setting Steps as below
- Firstly to press **【SET】** to change the hour , press **【UP/DOWN】** to adjust hour.
- Press **【SET】** to change the minute, then press **【UP/DOWN】** to adjust the minutes
- Press **【SET】** to change the day, then press **【UP/DOWN】** to adjust the day

- Press **【SET】** , then all function setting finished.

Step 4, Working Time and Intensity Setting

- The machine can be set 4 different working groups, different working days and the different intensity..
 - Setting Steps as below.
1. First time to press **【MODE】** . Then press **【SET】** to set the START TIME of the 1stgroup. Press **【UP/DOWN】** to adjust the hours; Press **【SET】** and press **【UP/DOWN】** to adjust the minute; Press **【SET】** and press **【UP/DOWN】** to adjust the working day;
 2. Second time to press **【MODE】** . Then press **【SET】** to set the STOP TIME OF 1stgroup. Press **【UP/DOWN】** to adjust hours; Press **【SET】** and press **【UP/DOWN】** to adjust the minute
 3. Third time to press **【MODE】** to set the AROMA CONCENTRATION of 1st group . Press **【UP/DOWN】** to adjust the aroma concentration. Every time you can adjust 5% (such as 5%, 10%, 15 %....), the maximum is 95%, the minimum is 5%.
 4. The 1st group is set well; If continue to set the other working groups, continue to press **【MODE】** to finish the other 3 working groups at the same method.



- Notice: If run time across the 00:00. It needs to set two separate run groups. The 1st group STOP TIME is 23:59; The 2nd group START TIME should be 0:01.
- Press **【DOWN】** last 10 seconds to Restore factory settings.
- In each group, the STOP TIME could not be earlier than the START TIME.
- Press **【MODE】** last 3 seconds to unlock the program.